

EVH
phase 90



LIVE TO PLAY LIVE®

Dunlop
JIMDUNLOP.COM

92503003509 revB



EVH90 PHASE 90



DESCRIPTION

- Deep, rich phasing
- SCRIPT switch toggles between old school and modern phase sounds
- Custom EVH paint job

POWER

The EVH Phase 90 is powered by one 9 volt battery (remove bottom plate to install), a 9 volt AC adapter such as the Dunlop ECB003/ECB003EU, or a power supply such as the DC Brick™.

DIRECTIONS

- Run a cable from your guitar to the EVH Phase 90's INPUT jack and run another cable from the EVH Phase 90's OUTPUT jack to your amplifier.
- Start with the SPEED knob at 12 o'clock.
- Turn the effect on by depressing the footswitch.
- Rotate the SPEED knob clockwise for a faster phase effect or counterclockwise for a slower phase effect.
- Leave the SCRIPT switch out for modern Block logo phase sounds or push it in for vintage Script logo phase sounds.


SPECIFICATIONS

Input Impedance	1 MΩ
Output Impedance	10 kΩ
Signal to Noise*	>96 dB
Bypass	Hardwire
Current Draw	8.2 mA
Power Supply	9 volts DC

*A-weighted, $V_{ref} = 1 V_{rms}$

CONTROLS

- 1 SCRIPT switch engages Script mode
- 2 SPEED knob controls overall effect rate
- 3 FOOTSWITCH toggles effect on/bypass (blue LED indicates on)



DUNLOP MANUFACTURING, INC.
P.O. BOX 846 BENICIA, CA 94510 U.S.A.
TEL: 1-707-745-2722 FAX: 1-707-745-2658